

## Lan/Wifi: Add IP address in your windows driver port

For Lan Or Wifi Port printing, pls check the following Guide.

After you get the new IP address, you still need to add the new Lan/WIFI IP address in your computer driver port for you to use.

Please find POS-58-Series or POS-80-Series printer driver, right click it and choose the Printer Properties and add the new Lan (also named ethernet or net) IP address in the port list. The Exact adding way show as following pictures.



